

SS-5299: Manual file:

1. IMPORTANT:

- **Always read the instruction book carefully before using.**
- **This manual can be downloaded from our web page www.sogo.es**
- **Keep these instructions for future reference.**

2. Safety instructions for the user

General precautions during the use of electrical equipment

- Do not use the appliance for any other purpose than described in this manual.
- Do not use or store the appliance outdoors.
- Always place the appliance on to the flat and even surface.
- The unit must be used only for the intended purposes. No liability is accepted for damages arising from improper use or wrong handling. Misuse or improper handling may cause problems in the appliance and cause injury to the user.
- This product is intended for indoor, non-industrial, non-commercial and only for household use. Do not use the item outdoors or for any other purpose
- Ensure that the voltage indicated on the nameplate matches the mains voltage before plugging in the appliance.
- Always remove the plug from the power socket when the appliance is not in use. Do not leave the appliance unattended when switched on.
- Close supervision is necessary when any appliance is being used by or near children.
- Before cleaning or storing your appliance, always unplug the appliance from the power supply and let it cool down.
- The device is not completely disconnected from the power source, even after it has been turned off. To disconnect it completely, disconnect it from the mains plug.
- The appliances are not intended to be operated by means of an external timer or separate remote-control system.

Restrictions on use to avoid personal injury

- Do not place or operate this appliance near water sources.
- Do not place or operate the appliance and its power cord on or near hot surfaces (e.g., stove plates) or open flames.
- Do not leave the power cord hanging from sharp edges and keep away from hot objects and flames. Do not wind the cord around the appliance and do not bend it.
- Never use accessories that are not recommended by the manufacturer.
- The use of accessories not recommended or sold by the appliance manufacturer may result in fire, electric shock or injury to persons.
- When you want to remove the plug from the wall contact, please do this at the plug itself and not by pulling on the cable or the appliance itself.
- To avoid electric shock, make sure your hands are dry before plugging or unplugging.
- Do not use the device with wet hands, on damp floors or when the atmosphere is humid, there is a risk of electric shock.
- Never immerse the appliance or the plug-in water or any other liquid. In the event of the appliance falling in water, disconnect immediately from the mains supply and take it to an authorized service agent for repair before reusing.

- Do not use the appliance if it has fallen on the floor, if there are visible signs of damage or if it has a leak.
- Do not use the appliance if the cable or plug is damaged. In case of the cord be damaged, it must be replaced only by the manufacturer, its service agent or similarly qualified persons in order to avoid Hazard.
- In case of appliance malfunction, or if it has been damaged in any manner, return the appliance to the nearest authorized service facility for examination, repair or adjustment.

Restrictions on use when used with children and elders

- Children should be supervised to ensure that they do not play with the appliance.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Do not allow the children to use the appliance.
- Appliances can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instructions concerning use of the appliance in a safe way and understand the hazards involved.

Instructions to follow when using the appliance

- Avoid contacting moving parts of the appliance while in function.
- Turn off the appliance and disconnect from the mains supply before changing accessories or approaching movable parts in use.
- Do not connect the appliance to the mains until it is completely assembled and always disconnect the appliance before disassembling.
- To avoid any damage or dangerous ,It's forbidden to open the product shell without permission.
- All the detachable accessories can be washed with mild detergent and water. Juicing box is dishwasher safe.

CLEANING AND MAINTENANCE: Kindly refer to the cleaning and maintenance section for details on how to clean surfaces which comes in the contact of food.

Technical Specifications

Voltage	Frequency	Power
AC 220-240V	50-60Hz	100W

Parts description

1. Orange Cutter
2. Clasp
3. Pull Buckle
4. Power Indicator
5. Top Lid
6. Squeezing cones
7. Juice container
8. Motor Body
9. Power Button
10. Power cord

6. INSTRUCTIONS FOR USE

Product Specification:
Dual Orange squeezing function:

This juicer is equipped with an advanced dual orange squeezing function that allows user to squeeze of two orange halves simultaneously. This function speeds up the juice preparation process, making it ideal for those house hold which frequently consume freshly squeezed juices. The Juicer uses two separate cones that enable continuous juicing and ensure maximum juice extraction.

The dual squeezing function is designed to minimize waste and maximize the efficiency of the juicing process. Each cone operates independently, allowing user to juice simultaneously without compromising on quality. The powerful motor ensures that each orange is thoroughly squeezed, extracting every drop of juice while preserving the essential nutrients and flavours.

The dual orange squeezing function of this juicer offers a convenient and efficient way to enjoy fresh, nutrient-rich orange juice quickly and easily.

Auto Lift Squeezing Function:

The Auto Lift Squeezing Function in a juicer is an innovative juicing feature designed to enhance the juicing process. This innovative mechanism is integrated into some advanced juicers as this one.

How It Works:

After placing orange half on the top of juicing cone and turning on the appliance power, auto lift mechanism starts working. Juicing cones, start moving upwards pushing orange half against top lid. This motion helps in getting out of maximum juice by squeezing. Once the juicing process finishes juicing cone start moving downwards and after then you can lift the spout cover to fill the glass with freshly squeezed juice. Now you can remove the orange peels and place the new orange halves to use the juicer again.

Benefits:

Efficiency: This function helps in more efficient juice extraction and reduced manual adjustments.

Ease of Use: Equipped with a simple Power press button gives you ease of use without any need of heavy manoeuvre.

Enhanced Juice Quality: By ensuring optimal contact and pressure of the fruit, the Auto Lift Squeezing Function helps in extracting juice that is rich in flavour and nutrients, while minimizing the incorporation of bitter flavours from the fruit peel.

Speed: Increases the speed of the juicing process.

Overall, the Auto Lift Squeezing Function in a juicer is a feature that emphasizes convenience, efficiency, and the quality of the juice, making it a desirable option for everybody.

Built in orange cutter:

This Orange juicer is provided with Built in Juicer cutter, which not only give the user a completely new experience, but also save his time.

Description of the Built-in Orange Cutter:

A built-in orange cutter is a part which is typically integrated into the upper part of a juicer or within its lid. This feature has been added to automatically slice or section oranges (or other similar citrus fruits) in one simple action, preparing them instantly for juicing. The cutter usually consists of one sharp plastic blade which is positioned in such a way to that helps cut the fruit efficiently into two halves.

How It Works:

In order to use this function, place an orange on the juicer's platform, directly below the cutter. By pressing the lid down the orange is pushed upward against the fixed blades of the cutter. The blades slice through the orange dividing into 2 equal portions, which are ready for juicing.

Benefits of Juicer cutter:

This function eliminates the need for pre-cutting fruits with knives, saving time and effort and making the juicing process quicker. By cutting the fruits in 2 equal portions it ensures uniform extraction of juice and optimises juicing process, enhance juice extraction and reduce waste. The best part of it is that this function gives you experience of clean and efficient juicing.

Instruction for use:

1. Unroll the power cord completely before plugging in.
2. Connect the appliance to the mains.
3. Place the glass underneath spout to collect the juice
4. Place the orange halves in its juicing position and turn on the power button.
5. The juice start working the with Auto lift squeeze functioning units start extracting juice.
7. Collect the Juice in the glass and enjoy it.
6. To stop the appliance, simply press the same power button, juicer will stop extracting juice.
7. Remove cone and the filter for cleaning process.
8. Make sure that unit has been stopped before cleaning process.

7. CLEANING AND MAINTENANCE

- Unplug the appliance from the mains and let it stop completely before starting any cleaning.
- Except the motor part, all the detachable parts can be cleaned with detergent and water or in washing up liquid. Rinse thoroughly to remove all traces of detergent.
- Clean the appliance with a damp cloth with a few drops of washing-up liquid and then dry.
- Do not use solvents such as bleach, or abrasive products, for cleaning the appliance.
- Do not submerge the appliance in water or any other liquid, or place it under a running tap.
- It is advisable to clean the appliance regularly and remove any food remains.
- The following parts can be cleaned in the dishwasher: Cone, Strainer and juice box.

JUICING ADVICE

1. Citrus fruit juices should be consumed immediately and never stored in a metal container.
2. Citrus juices are ideal for mixing. For example, you can mix orange juice with lemon juice for extra vitamin C kick.
3. Freshly squeezed juice gives cocktails a better flavor. Lemon juice is also delicious in hot tea and additionally helps you build up your defences when you have a cold.

